

WARNING

Whilst in operation, parts (including exterior surfaces) of your equipment will become hot. Position the appliance so as to minimise the possibility of accidental touching.

CONSEQUENTIAL LOSS

Fortius does not accept any responsibility for loss of food, production time, profit, etc., which is as a consequence of a breakdown of the equipment.

GUARANTEE

Fortius equipment is covered by a 12 months parts & labour guarantee. All work will be carried out between 9.00am-5.00pm, Monday to Friday, excluding Bank Holidays.

If you require assistance, please call our Service Line on **01355 244 111**

Fortius offer a rapid spares service, direct to your door - call **01355 244 111**

Once the pan has been removed from the Hotplate, turn OFF. Operating the unit without a pan upon the Hotplate will invalidate the Guarantee.

PRECAUTIONS

1. Ensure that the electricity supply is adequate for the unit to be installed.
2. Remove all the packaging from the appliance. Remove the protective film covering the stainless steel panels.
3. When siting the unit, ensure that there is free airflow around and behind it and that vents are not blocked. Ensure the appliance is level. Ensure that there is a gap of at least 25mm between the vent and any connecting item (including walls).
4. Walls, partitions, kitchen furniture etc. in close proximity to the appliance must be of fireproof construction.
5. All appliances with an electrical loading of over 3kw must be connected to the supply by a qualified electrician, in accordance with Health & Safety At Work Acts, IEE regulations, BS codes of practice, building standards, Local Authority and Building Regulations etc. A suitable means of disconnecting such appliances from the power supply must be provided, having at least 3mm contact separation in all poles.

INSTALLATION OF THE BOILING UNIT

Before first use, “burn-off” the protective coating from the Hotplates as follows: -

1. Ensure that all controls are in the OFF position.
2. Turn the control knob to setting “6”, and allow the hotplates to heat up for 5 minutes without a pan.
3. Switch off and wait for the hotplates to cool. When cool, wipe over with a damp cloth. If necessary, use a little domestic cleaning powder or scouring pad.
4. Using a mild detergent, wipe all the surfaces. **Do not use abrasives.**
5. Wipe away any detergent residue with a clean, damp cloth.
6. After cleaning, switch the hotplate on for a few minutes in order to dry it off.

OPERATING INSTRUCTIONS

1. Ensure the appliance is level and correctly sited.
2. Switch on the power supply. The red neon will indicate that the power is “ON”.
3. Turn the control knob clockwise to the desired setting. The amber neon adjacent to the knob will indicate that power is going through to the Hotplate. The front hotplate(s) are controlled by the right-hand knob(s).
4. Turn OFF by rotating the knob(s) anti-clockwise to position “0”.
5. Once the pan has been removed from the Hotplate, turn OFF.
6. When not in use, turn OFF at the power supply.

OPERATING EFFICIENCY

1. Pan bottoms must be dry before placing on the hotplate.
2. Good quality pans of adequate size for the hotplates should be used.

CLEANING INSTRUCTIONS

1. Disconnect from the mains electricity supply.
2. Allow to cool.
3. Clean the body of the appliance with a damp cloth and detergent. **Do not use abrasives.**
4. Wait for the hotplates to cool. When cool, wipe over with a damp cloth. If necessary, use a little domestic cleaning powder or scouring pad.
5. Wipe away any detergent residue with a clean, damp cloth.

FORTIUS

Operating & Maintenance Instructions for the Fortius

FBT23L

FBT23

FBT423

Boiling Units

IMPORTANT

Please read this page carefully before installation and use. It is the owner's responsibility to warn users to wear suitable protection and to follow operating and cleaning instructions.

Foodservice Equipment Marketing Ltd
10 Carron Place
Kelvin Industrial Estate
East Kilbride
Glasgow
G75 0YL
Tel: 01355 244111 Fax: 01355 241471

Foodservice Equipment Marketing Ltd
10 Carron Place
Kelvin Industrial Estate
East Kilbride
Glasgow
G75 0YL

Tel: 01355 244111

Fax: 01355 241471