

## **WARNING**

Whilst in operation, parts (including exterior surfaces) of your equipment will become hot. Position the appliance so as to minimise the possibility of accidental touching.

## **CONSEQUENTIAL LOSS**

**Fortius** does not accept any responsibility for loss of food, production time, profit, etc., which is as a consequence of a breakdown of the equipment.

## **GUARANTEE**

**Fortius** equipment is covered by a 12 months parts & labour guarantee. All work will be carried out between 9.00am-5.00pm, Monday to Friday, excluding Bank Holidays.

If you require assistance, please call our Service Line on **01355 244 111**

**Fortius** offer a rapid spares service, direct to your door - call **01355 244 111**

## **PRECAUTIONS**

1. Ensure that the electricity supply is adequate for the unit to be installed.
2. Remove all the packaging from the appliance. Remove the protective film covering the stainless steel panels.
3. When siting the unit, ensure that there is free airflow around and behind it. Ensure the appliance is level. Ensure that there is a gap of at least 25mm between connecting item (including walls).
4. Walls, partitions, kitchen furniture etc. in close proximity to the appliance must be of fireproof construction.

## **INSTALLATION OF THE OVEN**

Before connecting to the electricity supply: -

1. Using a little mild detergent, wipe all the surfaces. **Do not use abrasives.** Take care not to touch the element.
2. Wipe away any detergent residue with a clean damp cloth.
3. Make sure the appliance is dry before use.

## **OPERATING INSTRUCTIONS**

1. Screw legs or feet into base of oven.
2. If legs are fitted, ensure that they are fully tightened into base before levelling with adjusters.
3. If feet are fitted, adjust to level the oven and lock into position by tightening locknut against the base.
4. Ensure the appliance is level and correctly sited.
5. Ensure the door closes correctly.

6. Ensure the shelf supports are correctly located in their brackets.
7. Ensure the shelves are correctly located on the shelf supports.
8. If 1/1 gastronorm containers are to be used, do not fit the shelves. The 1/1 gastronorm container will fit on its own runner.
9. Switch on the power supply. The red neon will indicate that the power is "ON".
10. Turn the control knob clockwise to the desired setting. The amber neon will indicate that power is going through to the element. NOTE : The fan will operate continuously once the control knob has been turned on.
11. Turn OFF by rotating the knob anti-clockwise to position "0".
12. The oven light is operated by the switch next to the control knob
13. When not in use, turn OFF at the power supply.

## **CLEANING INSTRUCTIONS**

1. Disconnect from the mains electricity supply.
2. Allow the oven to cool down.
3. Clean the body of the appliance with a damp cloth and detergent. **Do not use abrasives.**
4. To remove the shelves, push fully back into the oven and lift the rear end of the shelf to clear the shelf support runner.
5. To remove the shelf supports, lift to clear lower support bracket, swing towards centre of oven and then lower to clear upper support bracket.
6. Clean oven liner with a damp cloth and detergent. Do not use abrasives.
7. To refit the shelves, reverse section 4 & 5.

# FORTIUS

## **Operating & Maintenance Instructions for the Fortius**

**FCO63**

**FCO683**

**FCO96**

**CONVECTION OVENS**

**IMPORTANT**

**Please read this page carefully before installation and use. It is the owner's responsibility to warn users to wear suitable protection and to follow operating and cleaning instructions.**

Foodservice Equipment Marketing Ltd  
10 Carron Place  
Kelvin Industrial Estate  
East Kilbride  
Glasgow  
G75 0YL

Tel: 01355 244111 Fax: 01355 241471

**Foodservice Equipment Marketing Ltd**

**10 Carron Place**

**Kelvin Industrial Estate**

**East Kilbride**

**Glasgow**

**G75 0YL**

**Tel: 01355 244111**

**Fax: 01355 241471**