

WARNING

The gastronorm containers should only be removed for cleaning. Do not remove the gastronorm containers until they have cooled thoroughly.

Whilst in operation, parts (including exterior surfaces) of your equipment will become hot. Position the appliance so as to minimise the possibility of accidental touching.

CONSEQUENTIAL LOSS

Fortius does not accept any responsibility for loss of food, production time, profit, etc., which is as a consequence of a breakdown of the equipment.

GUARANTEE

Fortius equipment is covered by a 12 months parts & labour guarantee. All work will be carried out between 9.00am-5.00pm, Monday to Friday, excluding Bank Holidays.

If you require assistance, please call our Service Line on **01355 244 111**

Fortius offer a rapid spares service, direct to your door - call **01355 244 111**

PRECAUTIONS

1. Ensure that the electricity supply is adequate for the unit to be installed.
2. Remove all the packaging from the appliance. Remove the protective film covering the stainless steel panels.
3. When siting the unit, ensure that there is free airflow around and behind it and that vents are not blocked. Ensure the appliance is level. Ensure that there is a gap of at least 25mm between the vent and any connecting item (including walls).
4. Walls, partitions, kitchen furniture etc. in close proximity to the appliance must be of fireproof construction.

INSTALLATION OF THE BAINS MARIE

Before connecting to the electricity supply: -

1. Using a little mild detergent, wipe all the surfaces. **Do not use abrasives.** Take care not to touch the element.
2. Wipe away any detergent residue with a clean damp cloth.
3. Make sure the appliance is dry before use.

OPERATING INSTRUCTIONS

1. Ensure the appliance is level and correctly sited.

2. Pour in clean water to a depth of 3cm. **Ensure this level is maintained, so that it does not boil dry.** Once the unit has been operated with a water level below 2cm, the **Guarantee will become VOID.**
3. Switch on the power supply. The red neon will indicate that the power is "ON".
4. Turn the control knob clockwise to the desired setting. The amber neon adjacent to the knob will indicate that power is going through to the element.
5. Place your hot food into the containers.
6. Turn OFF by rotating the knob anti-clockwise to position "0".
7. When not in use, turn OFF at the power supply and empty out the water.

CLEANING INSTRUCTIONS

1. Disconnect from the mains electricity supply.
2. Allow to cool.
3. Clean the body of the appliance with a damp cloth and detergent. **Do not use abrasives.**
4. The food containers are removable to aid cleaning.
5. To change the water allow the unit to cool thoroughly, then remove the tank from the body of the machine and pour the water away. Clean the tank with a damp cloth and detergent, then replace the tank and fill with fresh water.

FORTIUS

Operating & Maintenance Instructions for the Fortius

FBG24W

FBG44W

Wet Bains-Maries

IMPORTANT

Please read this page carefully before installation and use. It is the owner's responsibility to warn users to wear suitable protection and to follow operating and cleaning instructions.

Foodservice Equipment Marketing Ltd
10 Carron Place
Kelvin Industrial Estate
East Kilbride
Glasgow
G75 0YL

Tel: 01355 244111 Fax: 01355 241471

Foodservice Equipment Marketing Ltd
10 Carron Place
Kelvin Industrial Estate
East Kilbride
Glasgow
G75 0YL

Tel: 01355 244111
Fax: 01355 241471